SERVICE BULLETIN 19092602


MODELS COVERED: 55PFL5604/F7, 55PFL5704/F7

DIGITAL MAINS COVERED:

ACLRYMMA-002 ACLRXMMA-001



When replacing the Digital Main, the antenna cable must be removed from the defective board installed on the replacement board.



Failure to move the cable will result in the lack of range for the microphone.

If the cable is missing order replacement cable WX1ACLRZW611.

SB092619